



产品型号: QR-W100S  
Model NO.: QR-W100S  
最新版本: V1.0  
[Latest version:V1.0](#)

日期 <a href="#">Date</a>	更新历史 <a href="#">Update history</a>	软件下载 <a href="#">download</a>
2013-5-22	QR-W100S 无双向传输功能程序文件 V1.0.版本发布 <a href="#">QR-W100S No way transmission function programe document V1.0 version released</a>	QR-W100s nTx v1.0
	QR-W100S 双向传输功能程序文件 V1.0.版本发布 <a href="#">QR-W100S Bidirectional transmission function programe document V1.0 version released</a>	QR-W100s Tx v1.0

最新版本更新说明

[latest version update details](#)

升级注意事项:

**Note:**

1. 升级程序需使用 UP02 及 UP02 适配器为升级工具

**1: It's necessary to use the UP02 and UP02 adaptor for this upgrade steps.**

2. 本次程序为出厂程序, 提供了有双向传输功能的升级程序

**2: The procedure for the factory program, that provides two-way transmission function of the upgrade process**

电脑安装好 UP02 软件, 在 USB 端口插入 **UP02**, 并打开软件升级界面, 点击 “**connect**” 使通信端口联接上; 按下图接好 UP02 适配器的三芯插头到接收器上, 再接上电池


[Install the UP02 software in the PC,connect the UP02 with the USB,and open the software upgrade interface , click “Close”connect with software;](#)

[Please refer to below Illustration and connect the UP02 adaptor with the receiver , and then connect with the battery.](#)



在下面界面会出现已检测的机型型号和版本

[The model NO. and version will show in below interface .](#)



按 User Manual v1.0.pdf 说明操作。选择升级文件及升级操作

Please refer to User Manual V.10.PDF user manual, and select the upgrade document and upgrade steps.

附：enclosed with the user manual of the UP02.



## UP02适配器使用说明

### UP02 adaptor user manual

本产品用于三种不同插座的接收器升级转换。

1. 四芯：黑蓝黄红四线升级转接插头，用于间距1.25mm四芯直座的接收器升级。
2. 三芯：黑红蓝线和黑红黄线升级转接插头，用于间距1.25mm三芯直座的接收器升级。
3. 单线：黄色、蓝色和黑色单线升级转接插头，用于标准插座的接收器升级。

This adaptor used for connecting with UP02 and receivers with three different jacks to upgrade.

1. 4 cores jack: Plug the jack with black, blue, yellow and red four different colors' wire to the receiver's 4 cores jack which is 1.25 mm space between the 4 cores.
2. 3 cores jack: Plug the jack with black, blue and red three different colors' wire to the receiver's 3 cores jack which is 1.25 mm space between the 3 cores.
3. Single wire: Plug the jack with yellow, blue and black single wire to the standard receivers for upgrade.

示意图：  
see the illustration:

