




Install the UP02 software on the computer, and connect the UP02 kits with the USB port, when open the upgrade software window, please click “connect”; find out the upgrtading port in the QR X350 battery compartment; please connect the wire as bellow correctly to the QR X350 upgrade port, then connect the battery(3 colors upgrading wires connected as showed in the picture)



升级端口线颜色对应 Upgrade port line color corresponds to	
X350 升级端口线颜色 X350 Upgrade Port Line Color	UP02适配器升级线颜色 UP02 upgrade line color
Black 黑色	黑色 Black
red 红色	黄色 yellow
white 白色	蓝色 blue




The model NO. and version will show in below interface .



Firmware Upgrade, Please refer to User Manual V.10.PDF user manual, and select the upgrade document and upgrade steps.

Configuration upgrade , click the icon After the firmware upgrade procedure



Enclosed with the user manual of the UP02.

升级工具UP02使用说明

Upgrade tool—UP02 user manual

本产品用于DEVO-7遥控器和可升级的接收器升级。

This upgrade tool used for DEVO-7 radio and some receivers can be upgrade.

1. 安装UP02软件，下载升级机型程序。

1. Install the UP02 software, download the programe of the helicopters.

2. 按示意图连接好升级工具。

2. Please refer to the Illustration and connect the UP02 with PC.

DEVO-7遥控器升级时参照图（1）。

Illustration for upgrade the DEVO-7 radio refer to Illustration (1).

接收器升级时参照图（2），具体机型升级时参照产品说明书。

Illustration for upgrade the receiver refer to Illustration (2), please refer to the particular model's user manual for different model.

3. 升级。

3. Upgrade.

示意图：

See the Illustration:

连接电脑
Connect to the PC's USB

连接遥控器
Connect to the transmitter



图(1)

连接电脑
Connect to the PC's USB

连接UP02适配器
Connect to the UP02 Adapter

连接接收器
Connect to the receiver



图(2)

四芯
4 cores

三芯
3 cores

单线
Single wire

红(Red): VCC
黑(Black): GND
蓝(Blue): RX
黄(Yellow): TX

红(Red): VCC
黑(Black): GND
蓝(Blue): RX
黄(Yellow): TX

黑(Black): GND
蓝(Blue): RX
黄(Yellow): TX

四芯直座接收器
4 cores receiver

三芯直座接收器
3 cores receiver

标准插座接收器
standard receiver

UP02适配器使用说明 UP02 adaptor user manual

本产品用于三种不同插座的接收器升级转接。

1. 四芯：黑蓝黄红四线升级转接插头，用于间距1.25mm四芯直座的接收器升级。
2. 三芯：黑红蓝线和黑红黄线升级转接插头，用于间距1.25mm三芯直座的接收器升级。
3. 单线：黄色、蓝色和黑色单线升级转接插头，用于标准插座的接收器升级。

This adaptor used for connecting with UP02 and receivers with three different jacks to upgrade.

1. 4 cores jack: Plug the jack with black, blue, yellow and red four different colors' wire to the receiver's 4 cores jack which is 1.25 mm space between the 4 cores.
2. 3 cores jack: Plug the jack with black, blue and red three different colors' wire to the receiver's 3 cores jack which is 1.25 mm space between the 3 cores.
3. Single wire: Plug the jack with yellow, blue and black single wire to the standard receivers for upgrade.

示意图：
see the Illustration:

